

Crystolite®

Installation/Operation Manual

December 3rd, 2019

Crystolite® media should be properly backwashed & rinsed before placing into service. Requirement for **Top & Bottom** distributor **0.5 mm**

Installation Basic (for first time installation only!)

1. Open the new bag of **Crystolite®** media and put into the pressure vessel
2. Fill up the pressure vessel slowly with fresh water from bottom to the top (backwash mode)
3. Start backwashing the media for minimum 20 minutes (or if any fines are still visible in the backwash water) at 25 – 30 m/h [10 – 12 gpm/ft²].
4. After backwash is complete. Perform fast rinse for minimum 5 minutes @ 20 m/h [8 gpm/ft²].

